

TECHNICAL DATA SHEET

Hydrosan Pink disinfectant cleaner

An excellent disinfectant cleaner containing G-cide technology



SANS 1615 Type 1
Act29GNR529/240549/110/717



ECP201511010-1-2

DESCRIPTION

Hydrosan pink disinfectant cleaner is a clear, pink, pleasantly fragranced solution mainly used on all hard surfaces. This product contains 10% Glutaral C11-C15 Pareth 9 and all biodegradable ingredients. It is registered with the SABS as a disinfectant / detergent for general use.

APPLICATIONS

Hydrosan pink disinfectant cleaner is used to clean and disinfect walls, floors, all hard surfaces in homes, and all high risk areas where surfaces need to be sterile.

PROPERTIES

Appearance:	Pink, clear solution
Solubility:	100% in water and alcohol
pH:	Ideally between 7.3- 8.5 However during the shelf life the pH tends to drop And the range of acceptable pH is 6.0 - 8.5
% active G-cide.	10%

PRODUCT FEATURES

1. Does not contain any nitrosamine forming ingredients
2. Contains G-cide technology
3. All ingredients biodegrade >90% within 72 hours.
4. Non corrosive.
5. Kills all known bacteria, fungi and viruses > 99.9%.
6. Effectively cleans all surfaces.

DIRECTIONS FOR USE

1. HIGH RISK AREAS:

Use undiluted.

For P. aeruginosa, Ecoli, S.aureus a contact time of five minutes is required.

For black fungus, use the product as is.

2. INTERMEDIATE RISK AREAS:

Dilute 40 times (250mls of product per 9750mls of water).

For Aspergiler Niger a contact time of twenty minutes is required.

3. LOW RISK AREAS:

Dilute 100 times (100mls of product per 9900mls of water).

General instructions for use:

Dilute the product as per instructions above and put the solution in a spray bottle.

Apply to the surface area to be cleaned using a mop/pad/cloth and spread over the surface.

Allow contact time of five minutes.

Rinse well with water and allow to dry.

SAFETY PRECAUTIONS AND FIRST AID

Eyes:	Irritant, flush eyes with wash. Seek medical help
Skin:	Do not apply to dermatitis skin. Wash with water.
Ingestion:	Do not induce vomiting and immediate seek medical help.
Inhalation:	Remove to fresh air. If symptoms persist seek medical help.

STORAGE

Store tightly sealed containers in cool, dry area away from direct sunlight and sources of heat. Shelf life of properly stored material is at least one year from date of manufacture

PACKAGING

Available pack sizes are 5 L containers

Disclaimer

The information contained herein is based on the present state of information and knowledge available. The information provided are guidelines and recommendations and **does not** constitute any guarantee or warranty. Columbus Cleaning Solutions does not accept any liability of any kind for any loss including, without limitations, consequential loss, injury or damage arising from the use of its products and or information contained herein.

REF: HYD-P10
DATE: 08.08.2015